

Installing EMT

From exigowiki

EMT, or Exigo Management Tool, is the tool which is used to configure Exigo. EMT runs on **Windows 7, 8 and 10**.

The Exigo Management Tool connects to the system via the IP network and can be used online or offline.

Contents

- 1 Installing EMT
- 2 EMT Options
 - 2.1 Project Database Path
 - 2.2 Logging
- 3 EMT version




Exigo Management Tool

Installing EMT

To install the **Exigo Management Tool** on your PC:

- Download the latest version of the Exigo Management Tool (EMT): Downloads
- Double-click the setup file for the program



Click Next


- Click **Next** and **Accept** the EULA
- Follow the instructions in the InstallShield wizard until completion

After installation, all project database files will be stored on the hard disk under: **/Documents/Exigo/Projects/**.

EMT Options

Project Database Path


The default setting for storing databases is: **C:\Users\'your_name'\Documents\Exigo\Projects**
This can be changed by pressing the gears symbol on top right and select options:



Select the **Projects** tab in the bottom left. Here it is possible to change the **Project Database Path**.

Logging


For debugging of Exigo Management Tool you need to change the logging.
This is done by pressing the gears symbol on top right and select options:



Select the **Logging** tab in the bottom left.
Slide the **Log Level** slider all the way to the right (**Debug**).

EMT version

To check the EMT version click on the gear button (top left) -> Help



Retrieved from "https://exigowiki.zenitel.com/index.php?title=Installing_EMT&oldid=7588"

Categories: Getting started | EMT

-
- This page was last modified on 15 December 2016, at 13:26.